




# Buggy CLUTCH

## EXPLODED VIEW INSTRUCTIONS



71020/13	13 pinion gear
71020/14	14 pinion gear

### OPTIONAL

	71021/09 (Ø 0.90 mm)
	71021/11 (Ø 1.10 mm)
	<b>KIT 71021/K</b> (71021/09+71021/10+71021/11)
	71022/A (aluminium)
	71022/P (CFM)

### INSTRUCTIONS:

- Place the cone 20600 on your engine's crankshaft;
- Put the 4 springs on the shoes (71022/A and 71022/P) and insert on the flywheel's (71024) pins;
- Assemble the closing 71023 centering the final part of the springs with the four cut outs on the flywheel;
- Turn anti clock wise and push the closing towards the flywheel;
- Put the complete flywheel on your engine's crankshaft securing it with 71025.

### ISTRUZIONI:

- Sostituire il cono presente sul motore con quello fornito in dotazione;
- posizionare le molle sui ceppi (71022/A e 71022/P) e mettere il tutto sui perni del volano 71024;
- montare la chiusura 71023 centrando le parti terminali delle molle con le quattro fresature;
- ruotare in senso anti orario e spingere verso il volano la chiusura;
- montare la frizione sull'albero motore e bloccarla serrando il dado 71025.

